

Health N Massage®

SHIATSU DELUXE CUSHIONED BACK MASSAGER



ITEM NO: 900802

MODEL NO: KM8561AA

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE. KEEP AWAY FROM WATER

Keep this appliance out of the reach of children and infirm persons. Young children should be supervised to ensure that they do not play with the appliance.

DANGER – To reduce the risk of electric shock:

1. Always unplug this appliance from the electrical outlet immediately after using and before cleaning.
2. **DO NOT** reach for a product that has fallen into water. Unplug it immediately.
3. **DO NOT** use while bathing or in the shower.
4. **DO NOT** place or store appliance where it can fall or be pulled into a tub or sink.
5. **DO NOT** place in or drop into water or other liquid.

WARNING – To reduce the risk of burns, fire, electric shock, or injury to persons:

1. This appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
2. **DO NOT** operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
3. Use this appliance only for its intended use as described in this manual. **DO NOT** use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.
5. **DO NOT** carry this appliance by supply cord or use cord as a handle.
6. Keep the cord away from heated surfaces.
7. Never drop or insert any object into any opening.
8. To disconnect turn controls to the off (0) position, then remove plug from outlet.
9. Never use while sleeping or drowsy
10. **CAUTION: DO NOT** use continuously for more than 20 minutes

PRODUCT CARE AND MAINTENANCE

- Place cushion massager in a safe, cool and dry place when out in use.
- Wipe with a soft, damp cloth. **DO NOT** use abrasive cleaner.
- Never submerge the unit in any liquid. Keep away from all solvents and harsh detergents.
- **DO NOT** dry clean.
- **DO NOT** attempt to repair this cushion massager. There are no user-serviceable parts.

NOTE: this unit has a thermostat that may cause the motor and unit to cycle “OFF” if it is kept on for an extended period of time or if the motor overheats. If the unit turns “OFF” by itself, allow the unit to cool down before attempting to use it again.

Special Features of Your HEALTH N MASSAGE Shiatsu Deluxe Cushioned Back Massager

The HEALTH N MASSAGE Shiatsu Deluxe Cushioned Back Massager has unique design features to help enhance your massage experience:

- Four Rotating Shiatsu Back Massage Nodes for complete, soothing upper- and lower-back relief.
- Contoured Hand-held Controller for easy, convenient operation.

Note to User: Do not use the massager on the following body areas in these instances:

- A. Any area of the body that is swollen, burned or inflamed or where skin eruptions or ulcerated sores are present.
- B. Any area of the body that is anaesthetized or lacks the ability to sense heat, pressure or pain unless approved by your physician.
- C. The abdomen when pain is present.
- D. Legs with varicose veins.
- E. Calves of legs with explained pain.
- F. On or near the carotid artery on the left or right side of the neck.

NOTE: Massage should be pleasant and comfortable. Should pain or discomfort result, discontinue use and consult your physician.

HOW TO USE

1. Place the massager on a comfortable chair using the strap provided on the back of the massager to secure it to the chair.
2. Make sure the control switch is in the OFF position. Plug the cord into an electrical outlet.
3. The four rotating Shiatsu massage nodes can rotate in two directions to provide deep muscle relief (see figure A). Turn the massager on by sliding the massage control switch to the (*) position to rotate the nodes in one direction, or slide the switch to the (X) position to have the nodes rotate in an opposite direction (see Figure B). Slide the switch to the center position to turn the massager off.

NOTE: If you feel any pain or discomfort, discontinue use immediately.

4. DO NOT use for more than 20 minutes of continuous use.
5. WHEN NOT IN USE: Turn the appliance OFF, unplug it from the electrical supply source and store it in a dry place away from children.

NOTE: This unit has a thermostat that may cause the motor and unit to cycle "OFF" if it is kept on for an extended period of time or if the motor overheats. If the unit turns "OFF" by itself, allow the unit to cool down before attempting to use it again.

