



Bread Box USER MANUAL




**ITEM NO: 900777
MODEL NO: RG-8001**

IMPORTANT SAFEGUARDS

When using the electrical appliances, basic safety precautions should always be followed, including the following:

- Read this instruction booklet carefully before operation.
- Before using the appliance, check that the mains power voltage corresponds with the voltage shown on the rating plate.
- The appliance should be connected to a correctly earthed power socket.
- Always remove the plug from the power socket when the appliance is not in use and before carrying out any maintenance operations.
- Never leave the appliance unattended when it is switched on.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.
- This appliance is for domestic use only. Commercial use voids warranty. Use as described in this instruction booklet.
- Do not switch the appliance on if it appears to be faulty in any way.
- To protect against electric shock, do not immerse cords, plugs or the appliances in water or any other liquid.
- Do not let the power cord hang over the edge of a table or counter or let it come into contact with any hot surfaces.
- Unplug from outlet when not in use or before cleaning.
- Do not use this product for anything other than its intended use.
- To disconnect – remove the plug from the outlet. Do not pull plug out by the cord.
- For repairs or accessories contact the distributor on the contact details outlined in the guarantee.

PRODUCT DESCRIPTION




1. Release vacuum valve button

2. Cover Lock

3. On/Off Switch

4. LED control lamp

5. Battery Compartment



- 6. Transparent Cover
- 7. Vacuum Pump Filter
- 8. Vacuum Seal
- 9. Battery Compartment
- 10. Adaptor socket

About the Product:

- This Vacuum Seal Bread Box is great for preserving the freshness of Breads, Cakes, Fruits and Vegetables.
- Vacuum seal design expels the air to keep the food fresher and nutritious for longer.
- You can use it at home or take with you to picnics or holidays.
- Built in strong air pump.
- Simple to use locking system and air fill valve.
- Operate with AC adaptor or with batteries.

How to use

To Open:

Press the **Release vacuum valve button** in order to get the air in so you could open the box.

Push the **Cover Lock** into unlock position.

Lift the box lid.

Placing Food inside the box:

Once the box lid is open, you can fit any solid food inside.

Do not overfill as you won't be able to close the lid.

To Close:

After you fit your food inside the box:

Close the lid.

Lock the lid.

Plug the power adaptor into the power socket (or install batteries)

Press the vacuum button and leave it.

The strong pump will pump all the air out in a few minutes.

Once the air is pumped out, the pump will stop automatically.