



Air Cooler / Humidifier

User Manual



Model No.: KYT-12
Item No.: 900591
Rev 2

1	Safety Instructions	3
2	Components	5
3	Specifications	5
4	Instructions For Use	6
4.1	Preparation	6
4.2	On / Off	6
4.3	Speed	6
4.4	Timer	6
4.5	Cool	6
4.6	Swing	6
4.7	Mode	6
5	Care and Cleaning	7
6	Guarantee	7

1 Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Carefully read this instruction manual before using appliance.
- Keep appliance out of reach of young children.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Ensure children and babies do not play with plastic bags or any packaging materials.
- Do Not disassemble the appliance. There are no user serviceable parts inside.
- **VERY IMPORTANT:**
Ensure that appliance does not get wet (water splashes etc.).
Do not use appliance with wet hands.
Do not immerse appliance in water or other liquids or use near sinks, baths or showers.
- Always operate the appliance from a power source of the same voltage, frequency and rating as indicated on the product identification plate.
- Position the power supply lead properly so that they will not be walked on or pinched by items placed on or against them.
- Use appliance only for its intended use. Appliance is intended for household use only and not for commercial or industrial use.
- Do not use appliance if it has been dropped or any part of appliance (including cord or plug) has been damaged. Take appliance to your nearest authorised service centre or qualified dealer for inspection or repair.
- Use only accessories recommended or supplied by an authorised service centre or qualified dealer. The use of accessories not intended for use with this appliance may cause injuries to the user or damage to the appliance.
- Do not install the unit on other appliances, on uneven surfaces or where it could be subject to: heat sources (e.g. radiators or stoves), direct sunlight, excessive dust or mechanical vibrations.
- Appliance should not be used outdoors, placed near a hot gas or electrical burner or placed in a heated oven.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not operate appliance underneath or near flammable or combustible materials (e.g. curtains). Keep at least 300mm clearance around sides, back, front and top.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

- Do not block any ventilation openings.
- Never put objects into the louver when the unit is working
- Turn off and unplug before cleaning or storing.
- Any type of servicing, apart from ordinary cleaning, must be carried out by an authorised service centre or qualified dealer. There are no user serviceable parts in this appliance.
- If this appliance is used by a third party, please supply the instruction manual with it.
- Do not misuse the cord. Never carry the appliance by the cord or pull to disconnect it from the outlet. Instead, grasp the plug and pull to disconnect.
- Do not insert or allow foreign objects to enter the grille openings as this may cause damage to the appliance and/or injury to the user.
- Be sure the unit is placed on stable surface when operating.
- Turn off and unplug the unit before moving. Move the unit slowly and carefully. Never let the water overflow.
- Do not use the unit in very hot or humid places, such as kitchens, bathrooms or under direct sunlight.
- Turn off, unplug and empty the water from the unit if you are not going to use it for a long time.
- No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling of appliance.

Additional Safety Instructions

If using an extension cord:


- The cord should be checked and tested by an authorised service centre or a qualified dealer.
- The technical specifications of the extension cord must match or exceed the technical specifications of this appliance.
- Do not allow the cord to hang over the edge of the work surface or to come into contact with stoves or other hot surfaces.
- If the cord or plugs are worn or damaged, do not use.
- Unplug from the power socket by grasping the plug body - Do Not pull on the cord.

Read and Save These Instructions

2 Components



1. Control panel
2. Left-right louver
3. Up-down louver
4. Front body
5. Water level indicator
6. Water box entrance
7. Castor wheels



8. Handle
9. Water or Ice container(s)
10. Mesh filter
11. Power cord

3 Specifications

Model	Voltage (V)	Frequency (Hz)	Power Consumption (W)	Wind Vol. (M ³ /min)	Water Capacity (L)
KYT-12	230 - 240	50 / 60	60	21	10

4 Instructions For Use

4.1 Preparation

- Make sure that the power switch is set to OFF and the unit is disconnected from the power point.
- Pour cold water into the water box, until the level has reached the maximum.
- To make the water colder, take the two water / ice containers and pour pre-made ice inside, then put the two containers into the water box.
 - Alternatively, fill the two containers up with water the night before and place them in the freezer.

4.2 On / Off

- Insert the power cord into an outlet and turn on.
- Press the ON/OFF button on the control panel. You will hear a sound indicator like a beep and see a light indicator when the unit is turned on.

4.3 Speed

- By default, when the unit is turned "ON", it starts at low speed.
- Pressing the button one at a time, changes the Speed setting to "Mid", and then "High" until it goes back to "Low" speed. You will see a light indicator when you change any Speed setting.

4.4 Timer

- Use this function if you want the air cooler to turn off automatically. This is a power-saving feature especially at night.
- To set the Off time, press it one at a time to set the hour from 0.5h, 1h, 2h or 4h.
- To get the maximum 7.5h timer, continue pressing the button until all the indicator lights are on.

4.5 Cool

- Press this button if you want to have cool wind blowing from the air cooler.

4.6 Swing

- Press this button if you want to swing the vertical louver from left to right.
- Press it again to stop the left to right louver from swinging.

4.7 Mode

- Press this button if you want to feel varying breezes such as "Nature Breeze", "Normal Breeze" or "Sleeping Breeze".

5 Care and Cleaning

- Turn off and unplug the unit prior to cleaning.
- Clean the air cooler regularly especially the rear air inlet filter. Do not allow this filter to become blocked.
- Use a soft damp cloth or rag and mild detergent for cleaning and wipe dry.
- Never spray with liquids or submerge the unit in water or any other liquid.
- Do not use flammable liquids, chemicals, abrasive creams, steel wool or scouring pads for cleaning.

Read and Save These Instructions

6 Guarantee

What is Covered

H.E. Group Pty Ltd guarantees the appliance for a full replacement for a period of 12 Months from the date of purchase, which is only valid with the presentation of the original proof of purchase receipt.

This guarantee covers materials and workmanship defects only.

What is Not Covered

This guarantee does not apply to defects arising from abuse, alteration or unreasonable use of the product. In addition, it does not cover general deterioration due to usage.

This guarantee does not apply to the accessories, due to general wear and tear.

What H.E. Group Pty Ltd Will Do

H.E. Group Pty Ltd will replace the product, if a defect is discovered whilst under the guaranteed period, subject to verification of defect or malfunction, date and proof of purchase.

If you find you need to return the product under guarantee, please return it to the original place of purchase and ensure you have the original proof of purchase receipt, the original packaging and a brief description of why the product is being returned.

Customer Care

All enquiries may be directed to our toll free customer service number:
1800 079 124 or via email info@hegroup.com.au