

# Joli'e Foot Massager

MODEL - 900201

## INSTRUCTION MANUAL

---

### IMPORTANT SAFETY INSTRUCTIONS

**To reduce the risk of burns, fire, electric shock or injury to persons: -**

- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Do not use while bathing or showering.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, before putting on or taking off parts or attachments and before cleaning.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the supplier; specifically any attachments not provided with the unit.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return it to appropriated service centre for examination and repair.
- Keep cord away from heated surfaces.
- Never block the air openings of the appliance, or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep air openings free of lint, hair, dust, etc.
- Never use while sleeping or fall asleep while using the massager.
- Never drop or insert any object into any opening.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electrical shock or injury to persons.
- Do not carry this appliance by the supply cord or use the cord as a handle.
- Do not attempt to plug or unplug unit while feet are in the water.
- To disconnect, turn all controls to the "OFF" position, then remove the plug from outlet.
- This appliance is designed for household use only.
- Do not attempt to stand on or in the massager. Use only while seated.
- Use heated surface carefully. May cause serious burns. Do not use over sensitive skin areas or in the presence of poor circulation. The unattended use of heat by children or incapable persons may be dangerous.

### SAVE THESE INSTRUCTIONS

- This appliance has a heat function. People insensitive to heat must be specially careful during use.
- If you have any concerns regarding your health, consult your doctor before using the massager.
- Individuals with pacemakers should consult a physician before using this product.
- In case of pregnancy, diabetes or illness, consult your doctor before using massager.
- We recommend using this unit for no longer than 30 minutes at a time. Extensive use could cause the product to overheat. Should this occur, discontinue use and allow the

until to cool before operating.

- If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult your doctor. Persistent pain could be a symptom of a more serious condition.
- Never use any massager or infrared heat on open wounds, discolored areas, or any area of the body that is swollen, burned, inflamed or where skin eruptions or sores are present.
- Massage and infrared heat should be pleasant and comfortable. Should pain or discomfort result, discontinue use and consult your physician.

### **SPECIAL WARNINGS**

- Never immerse the massager in water or other fluids.
- Always check the temperature of the water before placing your feet into the massager.
- Do not stand in the unit. Sit down and place your feet in the massager
- Always unplug the unit when not in use and when filling, emptying, cleaning or moving the unit.
- The massager cannot be used to warm cold water. You must fill the unit with warm water and use heat only to maintain the temperature.
- Ensure that your hands are dry when operating the switch or removing the plug.
- Do not leave the massager unattended while it is operating.

**Heat will only maintain the temperature of water placed inside the massager. It will not heat cold water. For a warm water massage, please fill the unit with warm water.**

### **INSTRUCTIONS FOR USE**

1. Ensure that the unit is unplugged before filling with water.
2. Select the type of massage.  
**Dry Massage** The appliance may be used without water to massage your feet.  
**Wet Massage** To enjoy wet massage, fill the massager up with warm water.
3. Plug in and switch on. Turn the function dial to indicate the massage of your choice.

- 0 Off**
- 1 Massage**
- 2 Massage/Heat**

4. Sit down and place your feet in the spa.
5. To empty - First, unplug the unit. Tip the unit allowing water to spill out along the drain spout.  
**Never pour water over the control switch.**

### **MAINTENANCE**

#### **To Clean**

Unplug the unit and allow it to cool before cleaning. Clean only with a soft, damp cloth. Never allow water or any liquid to come into contact with the control switch.

- After cleaning, wipe surfaces with a dry cloth.
- Rollers can be removed for cleaning. Place thumb and forefinger around roller and pull out.
- Never use abrasives, detergents or cleaning agents.
- Periodically straighten the cord if it becomes twisted.

### **To Store**

Unplug the appliance from the outlet and allow to cool.

- Store in its box or a clean, dry place.
- To avoid breakage, do not wrap the power cord around the unit.
- Do not hang the unit by the power cord.
- This appliance is designed for household use only.